Maintenance Intervals for Porsche Vehicles

Modei	Model Year (MY)		Minor maintenance	Major maintenance	Annual maintenance*	Engine oli	Spark plugs	Oil filter	Air filter	Fuel filters	Coolant
	2001 - 2005	Carrera/ Carrera S	every 20,000 km/ 12,000 miles or every 2 years	every 40,000 km/ 24,000 miles or every 4 years	annual mileage of less than 15,000 km per year (only until MY 03)	every 20,000 km/ 12,000 miles or every 2 years	every 80,000 km/ 48,000 miles or every 4 years	every 20,000 km/ 12,000 miles or every 2 years	every 40,000 km/ 24,000 miles or every 4 years	every 80,000 km/ 48,000 miles (until MY 01)	does not require changing
		Turbo	every 20,000 km/ 12,000 miles or every 2 years	every 40,000 km/ 24,000 miles or every 4 years	annual mileage of less than 15,000 km per year (only until MY 03)	every 20,000 km/ 12,000 miles or every 2 years	every 40,000 km/ 24,000 miles	every 20,000 km/ 12,000 miles or every 2 years	every 40,000 km/ 24,000 miles or every 4 years	every 80,000 km/ 48,000 miles	does not require changing
		Carrera GT (as of MY 04)	every 20,000 km/ 12,000 miles or every 2 years	every 40,000 km/ 24,000 miles or every 4 years	annual mileage of less than 15,000 km per year	every 20,000 km/ 12,000 miles or every 2 years	every 40,000 km/ 24,000 miles or every 4 years	every 20,000 km/ 12,000 miles or every 2 years	every 20,000 km/ 12,000 miles or every 2 years	are maintenance-free	does not require changing
		GT2 / GT3	every 20,000 km/ 12,000 miles or every 2 years	every 40,000 km/ 24,000 miles or every 4 years	annual mileage of less than 15,000 km per year (only until MY 03)	every 20,000 km/ 12,000 miles or every 2 years	every 40,000 km/ 24,000 miles	every 20,000 km/ 12,000 miles or every 2 years	every 40,000 km/ 24,000 miles or every 4 years	every 80,000 km/ 48,000 miles	does not require changing
	2005 - 2007	Carrera/ Carrera S	every 30,000 km/ 20,000 miles or every 2 years	every 60,000 km/ 40,000 miles or every 4 years	-	every 30,000 km/ 20,000 miles or every 2 years	every 90,000 km/ 60,000 miles or every 4 years	every 30,000 km/ 20,000 miles or every 2 years	every 60,000 km/ 40,000 miles or every 4 years	are maintenance-free	does not require changing
Porsche 911		Turbo (as of MY 07)	every 30,000 km/ 20,000 miles or every 2 years	every 60,000 km/ 40,000 miles or every 4 years		every 30,000 km/ 20,000 miles or every 2 years	every 60,000 km/ 40,000 miles or every 4 years	every 30,000 km/ 20,000 miles or every 2 years	every 60,000 km/ 40,000 miles or every 4 years	every 90,000 km/ 60,000 miles or every 6 years	does not require changing
		Carrera GT (until MY 06)	every 20,000 km/ 12,000 miles or every 2 years	every 40,000 km/ 24,000 miles or every 4 years	annual mileage of less than 15,000 km per year	every 20,000 km/ 12,000 miles or every 2 years	every 40,000 km/ 24,000 miles or every 4 years	every 20,000 km/ 12,000 miles or every 2 years	every 20,000 km/ 12,000 miles or every 2 years	are maintenance-free	does not require changing
		GT3 (as of MY 07)	every 20,000 km/ 12,000 miles or every 2 years	every 40,000 km/ 24,000 miles or every 4 years		every 20,000 km/ 12,000 miles or every 2 years	every 40,000 km/ 24,000 miles or every 4 years	every 40,000 km/ 24,000 miles or every 4 years	every 40,000 km/ 24,000 miles or every 4 years	every 80,000 km/ 48,000 miles or every 6 years	does not require changing
	as of 2008	Carrera/ Carrera S	every 20.000 km/12.000 miles or every 1 year and every 40.000 km/24.000 miles or every 2 years	every 60,000 km/ 36,000 miles or every 3 years	-	every 20.000 km/ 12.000 miles or every 1 year	every 60.000 km/ 36.000 miles or every 4 years	every 20.000 km/ 12.000 miles or every 1 year	every 60.000 km/ 36.000 miles or every 3 years	are maintenance-free	does not require changing
		Turbo	every 20.000 km/12.000 miles or every 1 year and every 40.000 km/24.000 miles or every 2 years	every 60.000 km/ 36.000 miles or every 3 years		every 20.000 km/ 12.000 miles or every 1 year	every 40.000 km/ 24.000 miles or every 4 years	every 20.000 km/ 12.000 miles or every 1 year	every 60.000 km/ 36.000 miles or every 3 years	every 80,000 km/ 48,000 miles or every 6 years	does not require changing
		GT2	every 20.000 km/ 12.000 miles or every 2 years	every 40.000 km/ 24.000 miles or every 4 years		every 20.000 km/ 12.000 miles or every 1 year	every 20.000 km/ 12.000 miles or every 2 years	every 20.000 km/ 12.000 miles or every 1 year	every 40.000 km/ 24.000 miles or every 2 years	every 80,000 km/ 48,000 miles or every 6 years	does not require changing
		GT3	every 20.000 km/ 12.000 miles or every 2 years	every 40.000 km/ 24.000 miles or every 4 years		every 20.000 km/ 12.000 miles or every 1 year	every 40.000 km/ 24.000 miles or every 4 years	every 20.000 km/ 12.000 miles or every 1 year	every 40.000 km/ 24.000 miles or every 4 years	every 80,000 km/ 48,000 miles or every 6 years	does not require changing

* On vehicles with an annual mileage of less than 15,000 km (9,000 mls), annual maintenance must be carried out once a year. For an annual mileage of more than 15,000 km (9,000 mls) we recommend carrying out the next scheduled maintenance straight away (minor or major maintenance).

Maintenance Intervals for Porsche Vehicles

Model	Model Year (MY)		Minor maintenance	Major maintenance	Annual maintenance*	Engine oli	Spark plugs	Oil filter	Air filter	Fuel filters	Coolant
	2001 - 2004	Boxster/ Boxster S	every 20,000 km/ 12,000 miles or every 2 years	every 40,000 km/ 24,000 miles or every 4 years	annual mileage of less than 15,000 km per year (only until MY 03)	every 20,000 km/ 12,000 miles or every 2 years	every 80,000 km/ 48,000 miles or every 4 years	every 20,000 km/ 12,000 miles or every 2 years	every 40,000 km/ 24,000 miles or every 4 years	every 80,000 km/ 48,000 miles (until MY 01)	does not require changing
'orsche Boxste	2005 - 2007	Boxster/ Boxster S	every 30,000 km/ 20,000 miles or every 2 years	every 60,000 km/ 40,000 miles or every 4 years		every 30,000 km/ 20,000 miles or every 2 years	every 90,000 km/ 60,000 miles or every 4 years	every 30,000 km/ 20,000 miles or every 2 years	every 60,000 km/ 40,000 miles or every 4 years	are maintenance-free	does not require changing
	as of 2008	Box ster/ Boxster S	every 20.000 km/12.000 miles or every 1 year and every 40.000 km/24.000 miles or every 2 years	every 60.000 km/ 36.000 miles or every 3 years	-	every 20.000 km/ 12.000 miles or every 1 year	every 60.000 km/ 36.000 miles or every 4 years	every 20.000 km/ 12.000 miles or every 1 year	every 60.000 km/ 36.000 miles or every 3 years	are maintenance-free	does not require changing
Cayman	2006 - 2007	Cayman/ Cayman S	every 30,000 km/ 20,000 miles or every 2 years	every 60,000 km/ 40,000 miles or every 4 years		every 30,000 km/ 20,000 miles or every 2 years	every 90,000 km/ 60,000 miles or every 4 years	every 30,000 km/ 20,000 miles or every 2 years	every 60,000 km/ 40,000 miles or every 4 years	are maintenance-free	does not require changing
Porsche	as of 2008	Cayman/ Cayman S	every 20.000 km/12.000 miles or every 1 year and every 40.000 km/24.000 miles or every 2 years	every 60.000 km/ 36.000 miles or every 3 years	-	every 20.000 km/ 12.000 miles or every 1 year	every 60.000 km/ 36.000 miles or every 4 years	every 20.000 km/ 12.000 miles or every 1 year	every 60.000 km/ 36.000 miles or every 3 years	are maintenance-free	does not require changing

* On vehicles with an annual mileage of less than 15,000 km (9,000 mls), annual maintenance must be carried out once a year. For an annual mileage of more than 15,000 km (9,000 mls) we recommend carrying out the next scheduled maintenance straight away (minor or major maintenance).

Maintenance Intervals for Porsche Vehicles

Model	Model Year (MY)		Minor maintenance	Major maintenance	Annual maintenance	Engine oli	Spark plugs	Oil filter	Air filter	Fuel filters	Coolant
	2003 - 2006	Cayenne (as of MY 04)	every 30,000 km/ 20,000 miles or every 2 years	every 60,000 km/ 40,000 miles or every 4 years		In line with oil service indicator or no later than every 30,000 km/20,000 miles or every 2 years	every 60,000 km/ 40,000 miles or every 4 years	In line with oil service indicator or no later than every 30,000 km/20,000 miles or every 2 years	every 120,000 km/ 80,000 miles or every 4 years	are maintenance-free	does not require changing
		Cayenne S	every 30,000 km/ 20,000 miles or every 2 years	every 60,000 km/ 40,000 miles or every 4 years		every 30,000 km/ 20,000 miles or every 2 years	every 90,000 km/ 60,000 miles or every 4 years	every 30,000 km/ 20,000 miles or every 2 years	every 120,000 km/ 80,000 miles or every 4 years	are maintenance-free	does not require changing
Cayenne		Cayenne Turbo / Turbo S	every 30,000 km/ 20,000 miles or every 2 years	every 60,000 km/ 40,000 miles or every 4 years	-	every 30,000 km/ 20,000 miles or every 2 years	every 60,000 km/ 40,000 miles or every 4 years	every 30,000 km/ 20,000 miles or every 2 years	every 120,000 km/ 80,000 miles or every 4 years	are maintenance-free	does not require changing
Porsche (as of 2008	Cayenne	every 30.000 km/ 18.000 miles or every 2 years	every 60.000 km/ 36.000 miles or every 4 years		every 15.000 km/ 9.000 miles or every 1 year	every 60.000 km/ 36.000 miles or every 4 years	every 15.000 km/ 9.000 miles or every 1 year	every 120.000 km/ 72.000 miles or every 4 years	are maintenance-free	does not require changing
		Cayenne S	every 20.000 km/12.000 miles or every 1 year and every 40.000 km/24.000 miles or every 2 years	every 60.000 km/ 36.000 miles or every 3 years	-	every 20.000 km/ 12.000 miles or every 1 year	every 60.000 km/ 36.000 miles or every 4 years	every 20.000 km/ 12.000 miles or every 1 year	every 120.000 km/ 72.000 miles or every 4 years	are maintenance-free	does not require changing
		Cayerne Turbo / Turbo S	every 20.000 km/12.000 miles or every 1 year and every 40.000 km/24.000 miles or every 2 years	every 60.000 km/ 36.000 miles or every 3 years	-	every 20.000 km/ 12.000 miles or every 1 year	every 40.000 km/ 24.000 miles or every 4 years	every 20.000 km/ 12.000 miles or every 1 year	every 120.000 km/ 72.000 miles or every 4 years	are maintenance-free	does not require changing